

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Киргизия +996(312)96-26-47




Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

<https://alex.nt-rt.ru> || axa@nt-rt.ru



Колесики для тяжелых условий эксплуатации СЕРИЯ HLB-HU







СЕРИЯ HU-HLB





Код		 Kg		Подшипник					
2-1751	100	350	40		150x110	105x80	10	160	90
2-1752	125	400	40		150x110	105x80	10	183	106
2-1753	150	800	50		150x110	105x80	10	200	121
2-1754	200	1100	50		150x110	105x80	10	249	155
2-2294	250	1100	50		150x110	105x80	10	315	197
2-1755	250	1,250	50		180x170	150x135	16	315	197
2-3431	250	1500	75		180x170	150x135	16	315	197
4-1230	300	1,270	50		180x170	150x135	16	360	230
2-3432	300	1 900	75		180x170	150x135	16	360	230






СЕРИЯ HU-HLB

Код		 Kg		Подшипник					
2-1756	100	350	40		150x110	105x80	10	160	--
2-1757	125	400	40		150x110	105x80	10	183	--
2-1758	150	800	50		150x110	105x80	10	200	--
2-1759	200	1100	50		150x110	105x80	10	249	--
2-2295	250	1100	50		150x110	105x80	10	315	--

Код				Подшипник					
2-1760	250	1,250	50		180x170	150x135	16	315	--
2-3433	250	1500	75		180x170	150x135	16	315	--
4-1231	300	1,270	50		180x170	150x135	16	360	--
2-3434	300	1 900	75		180x170	150x135	16	360	--

СЕРИЯ HU-HLB

Код				Подшипник					
2-1761	150	800	50		150x110	105x80	10	200	121
2-1762	200	1100	50		150x110	105x80	10	249	155
2-2296	250	1100	50		150x110	105x80	10	315	197
2-1763	250	1,250	50		180x170	150x135	16	315	197
2-3742	250	1500	75		180x170	150x135	16	315	197
2-1538	300	1,270	50		180x170	150x135	16	360	230
2-3743	300	1 900	75		180x170	150x135	16	360	230

Код				Подшипник					
2-3367	100	350	40		150x110	105x80	10	160	90
2-3368	125	400	40		150x110	105x80	10	183	106
2-3369	150	800	50		150x110	105x80	10	200	121
2-3370	200	1100	50		150x110	105x80	10	249	155
2-3371	250	1100	50		150x110	105x80	10	315	197
2-3372	250	1,250	50		180x170	150x135	16	315	197
2-3546	250	1500	75		180x170	150x135	16	315	197
2-3373	300	1,270	57		180x170	150x135	16	360	230
2-3547	300	1 900	75		180x170	150x135	16	360	230

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (842)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47