

Алматы (7273)495-231
 Ангартск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

<https://alex.nt-rt.ru> || axa@nt-rt.ru

Черные резиновые колеса



Wheel HG

Code						Bearing	Color	Anti-wire Code
4-0514	100	200	38	20	45		Black	--
4-0516	125	250	38	20	45		Black	--
4-0518	150	400	50	20	60		Black	--
4-1642	150	400	50	25	60		Black	--
4-0235	200	600	50	20	60		Black	--
4-1643	200	600	50	25	60		Black	--
4-0523	250	700	50	25	60		Black	--
4-1639	250	750	75	25	82		Black	--
4-0526	300	750	50	25	60		Black	--
4-1640	300	850	75	25	82		Black	--



Wheel C

Code						Bearing	Color	Anti-wire Code
2-0083	200	300	38	20	55		Black	--
2-0078	200	300	38	20	55		Black	--
2-0084	250	400	50	25	64		Black	--
2-0079	250	400	50	25	64		Black	--

Code						Bearing	Color	Anti-wire Code
2-0085	300	450	53	25	71		Black	--
2-0080	300	450	53	25	71		Black	--



Wheel BS

Code						Bearing	Color	Anti-wire Code
2-0411	80	80	27	15	40		Black	2-0816
2-0412	100	110	27	15	40		Black	2-0816
4-0743	125	140	35	15	40		Black	2-0816
4-0744	160	180	37	20	60		Black	--
4-0745	200	230	46	20	60		Black	2-0818
4-0752	250	250	50	20	60		Black	--



Wheel PI

Code						Bearing	Color	Anti-wire Code
4-1562	80	30	26	8	35		Black	--
4-1563	100	35	30	10	35		Black	--

Code						Bearing	Color	Anti-wire Code
4-1564	125	50	35	15	44		Black	--
4-1290	150	80	38	15	44		Black	--
4-1291	175	100	41	20	58		Black	--
4-1292	200	120	48	20	58		Black	--
4-1293	250	130	48	25	58		Black	--
4-1294	300	150	60	25	74		Black	--





Wheel J

Code						Bearing	Color	Anti-wire Code
2-0209	200	160	35	20	40		Black	--
2-0368	230	200	36	20	40		Black	--
2-0369	250	230	40	20	40		Black	--




Wheel CA

Code						Bearing	Color	Anti-wire Code
2-0799	300	150	60	20	60		Black	--

Code						Bearing	Color	Anti-wire Code
4-0782	350	120	70	25	60		Black	--
4-0783	400	390	90	25	80		Black	--



Wheel TPG

Code						Bearing	Color	Anti-wire Code
2-0059	80	110	35	12	41		Black	--
2-1226	80	110	35	12	41		Black	--
2-0060	100	130	35	12	41		Black	--
2-1251	100	130	35	12	41		Black	--
2-0061	125	200	44	16	51		Black	2-0819
2-0785	125	200	44	17	53		Black	2-0819
2-0062	150	280	50	20	58		Black	2-0817
2-0786	150	280	50	20	53		Black	2-0817



Wheel PS

Code						Bearing	Color	Anti-wire Code
2-0848	80	75	27	12	40		Black	--
2-0849	100	100	27	12	40		Black	--
2-0850	125	125	35	12	40		Black	--
2-0851	150	150	35	12	40		Black	--
2-0852	160	160	40	20	60		Black	--
2-1122	160	160	40	20	60		Black	--
2-4739	160	160	40	20	60		Black	--
2-0853	200	215	47	20	60		Black	2-1250
2-1123	200	215	47	20	60		Black	2-1250
2-4740	200	215	47	20	60		Black	--



Wheel THG

Code						Bearing	Color	Anti-wire Code
2-4474	100	100	38	12	40		Black	--

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47

<https://alex.nt-rt.ru> || axa@nt-rt.ru