

Алматы (7273)495-231
 Ангарск (3955)60-70-56
 Архангельск (8182)63-90-72
 Астрахань (8512)99-46-04
 Барнаул (3852)73-04-60
 Белгород (4722)40-23-64
 Благовещенск (4162)22-76-07
 Брянск (4832)59-03-52
 Владивосток (423)249-28-31
 Владикавказ (8672)28-90-48
 Владимир (4922)49-43-18
 Волгоград (844)278-03-48
 Вологда (8172)26-41-59
 Воронеж (473)204-51-73
 Екатеринбург (343)384-55-89

Россия +7(495)268-04-70

Иваново (4932)77-34-06
 Ижевск (3412)26-03-58
 Иркутск (395)279-98-46
 Казань (843)206-01-48
 Калининград (4012)72-03-81
 Калуга (4842)92-23-67
 Кемерово (3842)65-04-62
 Киров (8332)68-02-04
 Коломна (4966)23-41-49
 Кострома (4942)77-07-48
 Краснодар (861)203-40-90
 Красноярск (391)204-63-61
 Курск (4712)77-13-04
 Курган (3522)50-90-47
 Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
 Москва (495)268-04-70
 Мурманск (8152)59-64-93
 Набережные Челны (8552)20-53-41
 Нижний Новгород (831)429-08-12
 Новокузнецк (3843)20-46-81
 Ноябрьск (3496)41-32-12
 Новосибирск (383)227-86-73
 Омск (3812)21-46-40
 Орел (4862)44-53-42
 Оренбург (3532)37-68-04
 Пенза (8412)22-31-16
 Петрозаводск (8142)55-98-37
 Псков (8112)59-10-37
 Пермь (342)205-81-47

Казахстан +7(7172)727-132

Ростов-на-Дону (863)308-18-15
 Рязань (4912)46-61-64
 Самара (846)206-03-16
 Санкт-Петербург (812)309-46-40
 Саратов (845)249-38-78
 Севастополь (8692)22-31-93
 Саранск (8342)22-96-24
 Симферополь (3652)67-13-56
 Смоленск (4812)29-41-54
 Сочи (862)225-72-31
 Ставрополь (8652)20-65-13
 Сургут (3462)77-98-35
 Сыктывкар (8212)25-95-17
 Тамбов (4752)50-40-97
 Тверь (4822)63-31-35

Киргизия +996(312)96-26-47

Тольятти (8482)63-91-07
 Томск (3822)98-41-53
 Тула (4872)33-79-87
 Тюмень (3452)66-21-18
 Ульяновск (8422)24-23-59
 Улан-Удэ (3012)59-97-51
 Уфа (347)229-48-12
 Хабаровск (4212)92-98-04
 Чебоксары (8352)28-53-07
 Челябинск (351)202-03-61
 Череповец (8202)49-02-64
 Чита (3022)38-34-83
 Якутск (4112)23-90-97
 Ярославль (4852)69-52-93

<https://alex.nt-rt.ru> || axa@nt-rt.ru

Серые резиновые колесики



Wheel CB

Code						Bearing	Color	Anti-wire Code
2-1139	125	100	32	8	41		Gray	Included




Wheel PCI

Code						Bearing	Color	Anti-wire Code
1-0324	30	15	16	5	20		Gray	--
1-0467	30	15	16	6	18.5		Gray	--
1-0468	40	17	16	5	22		Gray	--
1-0319	40	25	16	8	20		Gray	--
1-0399	50	30	18	10	20		Gray	2-2452
1-0321	60	35	18	10	20		Gray	2-1563
2-1064	60	40	22	10	27		Gray	2-1563
2-0806	80	60	24	10	27		Gray	2-0820
2-0787	100	70	25	10	27		Gray	2-0820





Wheel PGA

Code						Bearing	Color	Anti-wire Code
2-0807	80	80	32	8	40		Gray	2-2454
2-1312	80	80	32	12	40		Gray	2-2454
2-1124	100	110	32	8	40		Gray	2-0821
2-0784	100	110	32	12	40		Gray	2-0821
2-1125	125	135	32	8	40		Gray	2-2809
2-0790	125	135	32	12	40		Gray	2-8809
2-1253	150	140	32	8	40		Gray	2-0815
2-1252	150	140	32	12	40		Gray	2-0815
2-1569	200	160	32	8	42		Gray	Included



Wheel PGAIB

Code						Bearing	Color	Anti-wire Code
2-2759	100	85	32	8	43		Gray	Included
2-1146	125	90	32	8	43		Gray	Included
2-3577	150	100	32	8	43		Gray	Included



Wheel PGIB

Code						Bearing	Color	Anti-wire Code
2-2891	80	70	25	6	28		Gray	Included
2-2892	100	80	25	6	28		Gray	Included



Wheel PGZ

Code						Bearing	Color	Anti-wire Code
2-3142	80	80	28	12	40		Gray	--
2-3147	80	80	28	12	40		Gray	--
2-3310	80	80	28	12	40		Gray	--
2-3143	100	100	30	12	40		Gray	2-0822
2-3148	100	100	30	12	40		Gray	2-0822
2-3311	100	100	30	12	40		Gray	2-2809
2-3144	125	130	32	12	40		Gray	2-4485
2-3149	125	120	32	12	40		Gray	2-4485
2-3312	125	120	32	12	40		Gray	2.0815
2-3145	160	160	38	20	60		Gray	4-1190
2-3146	200	180	45	20	60		Gray	4-1582



Grey PS Wheel

Code						Bearing	Color	Anti-wire Code
2-3397	160	160	40	20	60		Gray	--
2-3398	160	160	40	20	60		Gray	--
2-4741	160	160	40	20	60		Gray	--
2-3548	160	160	40	12	60		Gray	Included
2-3395	200	215	47	20	60		Gray	2-1250
2-3396	200	215	47	20	60		Gray	2-1250
2-4742	200	215	47	20	60		Gray	--
2-3549	200	215	47	12	60		Gray	Included

Алматы (7273)495-231
Ангарск (3955)60-70-56
Архангельск (8182)63-90-72
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Благовещенск (4162)22-76-07
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Владикавказ (8672)28-90-48
Владимир (4922)49-43-18
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Коломна (4966)23-41-49
Кострома (4942)77-07-48
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Курган (3522)50-90-47
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Нижний Новгород (831)429-08-12
Новокузнецк (3843)20-46-81
Ноябрьск (3496)41-32-12
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16
Петрозаводск (8142)55-98-37
Псков (8112)59-10-37
Пермь (342)205-81-47

Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Саранск (8342)22-96-24
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13
Сургут (3462)77-98-35
Сыктывкар (8212)25-95-17
Тамбов (4752)50-40-97
Тверь (4822)63-31-35

Тольятти (8482)63-91-07
Томск (3822)98-41-53
Тула (4872)33-79-87
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Улан-Удэ (3012)59-97-51
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Чебоксары (8352)28-53-07
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Чита (3022)38-34-83
Якутск (4112)23-90-97
Ярославль (4852)69-52-93

Россия +7(495)268-04-70

Казахстан +7(7172)727-132

Киргизия +996(312)96-26-47